LABINCO L364 4-Pos. Flask Heater 450°C



Technical data

| Number of positions | 4 |
|--|---------------------------------|
| Heating quantity max. | 100-1000 ml (see flask holders) |
| Motor rating input | - |
| Motor rating output | - |
| Speed display | - |
| Speed range | - |
| Stirring bar length max. | - |
| Heat output | 450 W (1 Position) |
| Heating rate | 7 K/min |
| Heating temperature range | room temp 450 °C |
| Heat control | analog |
| Heat control accuracy | 1 ±K |
| Speed control | - |
| Adjustable safety circuit min. | - |
| Adjustable safety circuit max. | - |
| Connection for ext. temperature sensor | - |
| Control accuracy with sensor | - |
| Temperature constancy in medium | 1 ±K |
| Set-up plate material | steel coated |
| Set-up plate dimensions | Ø 85 mm |
| Dimensions (W x D x H) | 600 x 240 x 130 mm |
| Weight | 8.2 kg |
| Permissible ambient temperature | 5 - 60 °C |
| Permissible relative humidity | 80 % |
| Protection class according to DIN EN 60529 | IP 42 |
| RS 232 interface | - |

Product number

Voltage

Frequency

Power input

36400

220 - 230 V

50/60 Hz

1800 W

LABINCO L364 4-Pos. Flask Heater 450°C



Description

The model "L364" is a 4 pos. circular hotplate for fast heat transfer. Hotplates are 86 mm and 450 Watt.

Stepless thermostat setting provides thermostatically controlled hotplate.

Temperature from ambient up to 450 degr.C

Operating instructions

After unpacking, place model "L364" on a suitable surface. Put line cord into a suitable power-line (see specifications). You can switch on power with main-switch. You can switch the "heat control" in the ultimate counter clock-wise position, the hotplate is "off". Turning the "heater control" clockwise the hotplate will be energized and the pilot lamp will be lit, when the thermostat sensor detects a hotplate temperature to be equivalent to the "heater control" setting the thermostate will switch "off" and the pilot-lamp is put out.

After the hotplate-temperature has dropped some degrees, the thermostat will switch "on" and the pilot-lamp will lit again. In this way a constant top plate temperature will be reached.

The more the "heater-control" will be turned clockwise, the higher the temperature will rise before it stabelises.

| | TEL;0031(0)76-5417582 E-mail;info@labinco-bv.com | | http;//www.labinco-bv.com | |
|------------|---|--------|---------------------------|-----------------|
| | | | FAX;0031(0)76-5420173 | |
| | ZINKSTRAAT 64 | 4823AC | BREDA | THE NETHERLANDS |
| LABINCO BV | P.O.BOX 3259 | 4800DG | BREDA | THE NETHERLANDS |